

5" RUGGED ANDROID BARCODE SCANNER

CONKER SX5



 **CONKER.**

IT'S THIS RUGGED.

I65 Rated
Drop Tested from 1.2m onto concrete
Protected against water jets
Impervious to dust
Operating temperature between -20 °C
and 70 °C
Operating humidity between 5%-90%

YOUR BATTERY IS THIS GOOD.

4,000mAh battery

YOUR NETWORK IS THIS CAPABLE

Wifi: 802.11 a/b/g/n
Bluetooth
3G
GPS
Supports tethering and casting

THE MEMORY IS THIS BIG.

2GB RAM + 16GB storage

THE CAMERA IS THIS COOL.

8.0 Megapixel rear camera
2.0 Megapixel front camera

THE SIZE AND WEIGHT IS NO MORE THAN THIS.

Dimensions 147 x 78 x 18mm
Weight 245g

THE CONNECTIVITY IS THIS GOOD.

1 x 3.5mm Headphone jack
1 x Micro USB (OTG)
1 x Micro SD card
2 x SIM slot
2 x SAM slot
Waterproof internal microphone and loud
speaker

THE PROCESSOR IS THIS FAST.

MediaTek Quad Core 1.3GHz

DISPLAY IS THIS BRIGHT AND STRONG.

Display 5"IPS
Resolution 1280 x 720
Capacitive Multitouch screen with Gorilla glass





THE OPERATING SYSTEM IS.

Android 5.1

THE SENSORS CAN TELL YOU THIS MUCH.

Accelerometer
Gyroscope
Ambient light


HOW TO USE YOUR SX5 RUGGED DEVICE




1. Light sensor/ notification light
2. Ear piece
3. Front camera
4. Menu button
5. Home button
6. Back button
7. Camera flash
8. Rear Camera
9. NFC Antenna
10. Rear cover lock
11. Loud speaker
12. Volume buttons
13. Scan trigger
14. Power button
15. Scan trigger
16. Rear cover removal point
17. Barcode scanning window
18. Headphone jack


INSTALLING SIM AND MICRO SD CARD


To remove the back cover rotate the rear cover lock anti-clockwise




Lift battery cover beginning at the removal point indicated



 Always use right size of SIM card




Orientate the SIM and Micro SD card as per the picture below and also on the phone just above each SIM and SD card slot



Put the cover back on by putting it in position and pressing firmly around the perimeter of the cover. When fitted correctly there are no visible gaps.

Rotate the lock clockwise.




BARCODE SCANNING

To access the barcode scanner setting, enter “Settings” > “Barcode”

Here you can deactivate either or both trigger buttons to prevent accidental triggering. You can also set the barcode scanning mode and the suffix. By default the suffix is configured to be a carriage-return.

When scanning barcodes it is important to orientate your device per the picture below.



GET IN TOUCH

To contact Conker Support:

01279 295830

Support@weareconker.com

Conker
Calf Pens
Hatfield Park Farm
Takeley
CM22 6NG



Conker customers benefit from the UK's market leader in rugged device support. Contact us with complete confidence.

Thank you for purchasing a  CONKER.


CE Marking and European Economic Area




Tablet Technologies hereby declares that this equipment is in compliance with Directive 2011/65/EU and 1999/5/EC or 2014/53/EU. The following standards have been applied and tested. Conformity is limited to the essential requirements of the R&TTE.


For your safety

To reduce the potential risk of injury and or damage to equipment or property, always observe the following safety precautions.

 WARNING
Do not attempt to repair or modify the product as this could cause harm and will void any warranty.
Do not expose your skin to the product or AC adaptor when using the product for prolonged periods.
Do not puncture the product or battery.
Use only the specified battery (supplied).
Use only the specified AC adaptor (supplied).
Ensure all port and interface covers are closed before exposing the product directly to water or elevated levels of moisture or dust.
Packaging and accessories are choking hazards and should be kept out of reach of children.
Do not operate the product while driving.
Do not expose the AC Adaptor to water and do not use Adaptor when faulty.
Prolonged use of headphones can lead to a loss of hearing.

 CAUTION
Do not operate the product if it shows any visible signs of damage.
To prevent injury or harm, avoid looking directly at the flash or where applicable, the laser barcode scanner.
Do not expose the product to extreme temperatures for a prolonged period. Do not expose the product directly to your skin in extreme temperature environments.

Battery

 DANGER
The battery is for use solely with the specified product. Do not use it with any other products.
Do not use the battery if it becomes noticeably damaged or deformed.
Do not crush, bend, deform, puncture, shred, throw, or apply high pressure to the battery.
Only charge the battery with the supplied charger or cradle.
Do not subject the battery to an open flame or expose it to excessive heat.
Contents can combust under pressure.
If the electrolyte from the battery comes into contact with the eyes, skin, or clothing, rinse thoroughly with cold water and seek medical advice.



Battery Information

CAUTION. Use only approved batteries. Risk of explosion if battery is charged with an incompatible charger, exposed to heat >60C or replaced by an incorrect type.



European Battery Directive 2006/66/EC

Dispose of batteries separately and responsibly. All waste batteries are classified as hazardous waste and should be disposed of at a battery recycling centre.

Our rechargeable battery packs are designed and constructed to the highest standards within the industry. However, there are limitations to how long a battery can operate or be stored before needing replacement. Many factors affect the actual life cycle of a battery pack, such as heat, cold, harsh environmental conditions and severe drops. Batteries are considered chemical products. As such, battery performance will deteriorate over time if stored for a long period of time without being used. When batteries are stored over six (6) months, some irreversible deterioration in overall battery quality may occur. Store batteries at half of full charge in a dry, cool place, removed from the equipment to prevent loss of capacity, rusting of metallic parts and electrolyte leakage. When storing batteries for one year or longer, the charge level should be verified at least once a year and charged to half of full charge.

Replace the battery when a significant loss of run time is detected. Standard warranty period for all batteries is one year from order fulfilment, regardless if included as part of a mobile computer with a longer warranty duration or ongoing maintenance contract. The cycle life of batteries will vary according to the charge and discharge conditions, the temperature and other usage conditions. When used in accordance with the IEC charge and discharge specifications the typical cycle life of a battery is between 300 and 400 cycles at room temperature. Individual results may vary.

Lithium batteries do not suffer from “battery memory” therefore you do not need to fully charge to 100% or fully discharge to 0%. Complete discharge of batteries should always be avoided. Shallow discharge is preferable, i.e. recharge at 20% if possible.

Battery Safety Guidelines

- The area in which the units are charged should be clear of debris and combustible materials or chemicals.
- Improper battery use may result in a fire, explosion, or other hazard.
- To charge the mobile device battery, the battery and charger temperatures must be between 0°C and +40°C (+32°F to +104°F).
- Do not use incompatible batteries and chargers. Use of an incompatible battery or charger may present a risk of fire, explosion, leakage, or other hazard. If you have any questions about the compatibility of a battery or a charger, contact Tablet Technologies support.
- For devices that utilize a USB port as a charging source, the device shall only be connected to products that bear the USB-IF logo or have completed the USB-IF compliance programme.
- Do not disassemble or open, crush, bend or deform, puncture, or shred.
- Severe impact from dropping any battery-operated device on a hard surface could cause the battery to overheat.
- Do not short circuit a battery or allow metallic or conductive objects to contact the battery terminals.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, or expose to fire, explosion, or other hazard.
- Do not leave or store the equipment in or near areas that might get very hot, such as in a parked vehicle or near a radiator or other heat source.
- Do not place battery into a microwave oven or dryer.
- Battery usage by children should be supervised.
- Please follow local regulations to promptly dispose of used re-chargeable batteries.
- Do not dispose of batteries in fire.
- Seek medical advice immediately if a battery has been swallowed.
- In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with large amounts of water and seek medical advice immediately.
- If you suspect damage to your equipment or battery, contact Tablet Technologies support to arrange for inspection.

Class 2 Laser Product – Honeywell N4300 1D Laser Barcode Scanner

Safety Standards:

EN 60950-1:2005/Am1:2009,

IEC 60950-1:2006/A11:2009/A1:2010/A12:2011

Laser Safety Statement

This device has been tested in accordance with and complies with IEC 60825-1 ed2.0.

LASER LIGHT, DO NOT STARE INTO BEAM, CLASS 2 LASER PRODUCT, 1.0 mW MAX OUTPUT: 650nm.

Engine Laser Beam:

Wavelength 650 nm

Max power output 1mW

The laser diode is considered an embedded laser. Intrabeam viewing of the laser shall be prevented.

Embedded Laser:
Wavelength 650 nm
Max power output 10 mW

Caution - use of controls or adjustments or performance of procedures other than those specified by the manufacturer may result in hazardous radiation exposure.

